

Routine Maintenance - Service Indicator Intervals

Maintenance Item	Oil Service	Inspection I	Inspection II	Tools required	New parts required	Warm engine required	Dealer service recommended
Oil Change service							
• Change oil and oil filter	✓	✓	✓	✓	✓	✓	
Tune up							
• Check and adjust valve clearance		✓	✓	✓			
• Replace spark plugs			✓	✓	✓		
• Replace air filter			✓		✓		
• Replace main fuel filter			✓	✓	✓		
• Inspect ignition distributor cap, rotor and spark plug wires; replace as necessary			✓				
• Check idle mixture and adjust		✓	✓			✓	✓
Engine compartment maintenance							
• Check brake fluid level		✓	✓				
• Check clutch fluid level		✓	✓				
• Check automatic transmission fluid level and correct as necessary			✓				
• Check battery acid level and correct as necessary		✓	✓				
• Check engine coolant level and anti-freeze protection and add as necessary. Inspect for cooling system leaks		✓	✓				
• Lubricate accelerator linkage and throttle linkage with oil. Lubricate bearing of throttle plate with grease		✓	✓				
• Inspect V-belt tension and condition, and adjust or replace as necessary			✓	✓			

**Routine Maintenance - Service Indicator Intervals
(Continued)**

Maintenance Item	Oil Service	Inspection I	Inspection II	Tools required	New parts required	Warm engine required	Dealer service recommended
Under car Maintenance							
• Check manual transmission oil level and add as necessary		↙	↙	↙			
• Replace manual transmission oil			↙	↙			
• Replace automatic transmission fluid		↙			↙	↙	
• Check final drive fluid level		↙	↙				
• Replace final drive oil			↙	↙		↙	
• Check fuel tank, fuel lines, and all connections for leaks		↙	↙				
• Inspect exhaust system		↙	↙				
• Check power steering system for leaks. Check fluid Level		↙	↙				
• Check brake callipers and dust boots for leaks		↙	↙				
• Inspect brake system for damaged hoses and lines, leaks or damage		↙	↙				
• Check brake pad and shoe wear		↙	↙				
• Inspect parking brake cable, adjust as necessary		↙	↙				
• Inspect front suspension and steering for play		↙	↙				
• Inspect rear drive axle joint boots		↙	↙				
• Check front wheel bearing play			↙				
• Inspect wheels and tires, check tire pressure and condition		↙	↙				
• Inspect clutch for wear			↙	↙			
Body and interior maintenance							
• Lubricate door hinges		↙	↙				
• Check headlight and driving light aiming and adjust as necessary		↙	↙				↙
• Check operation of headlights, parking lights, back-up lights, license plate lights, interior lights, glove box light, engine compartment light, trunk light, instrument panel lights, turn signals, emergency flashers, stop lights, horns, headlight flasher and dimmer switch		↙	↙				
• Check active check control panel		↙	↙				
• Sliding sunroof, clean and lubricate slide rail			↙				
• Check function of air conditioning and refrigerant charge		↙	↙				↙
• Check function of seat belts		↙	↙				
• Check windshield washer fluid level and add as necessary, Check operation of washer system, Check condition of wiper blades		↙	↙				
Road Test							
• Check braking performance, steering heating and ventilation, automatic transmission, and mirrors		↙	↙				